

Beck Linen Chandelier

Installation & Care Guide — AIR HAVEN

SAFETY NOTICE: This is a hardwired lighting fixture. Installation should be performed by a qualified, licensed electrician in accordance with local electrical codes. Disconnect power at the circuit breaker and verify with a voltage tester before beginning any work.

Installation Steps

This is a hardwired fixture and should be installed by a qualified, licensed electrician in accordance with local electrical codes, with power disconnected at the breaker before work begins.

1. Turn off power to the circuit at the breaker box and confirm with a voltage tester.
2. Mount the ceiling bracket to the electrical junction box (the 5" back plate should fully cover the junction box opening).
3. Connect the fixture's wiring to the household wiring (ground, neutral, and live) inside the junction box.
4. Confirm your switch or dimmer is compatible with the dimmable push-button control method before making final connections.
5. Install the bulb(s) into the socket(s) before attaching the shade, if the shade's design makes the bulb hard to reach once assembled.
6. Slide the double-layer linen drum shade down over the frame and secure it in place, keeping the shade level and centered under the back plate.
7. Secure the fixture flush to the ceiling and restore power at the breaker, then test.

For vaulted or sloped ceilings, use a sloped-ceiling adapter kit if your canopy does not sit flush against the angled surface, and confirm compatibility before installation.

Care & Maintenance

The fixture's linen drum shade and metal frame should be cleaned gently to keep its finish and appearance looking new.

- Turn off power and let any bulb cool before cleaning.
- Dust the linen drum shade and metal frame with a soft, dry cloth on a regular basis.
- Avoid household glass/metal cleaners and abrasive pads, which can dull or scratch the finish.
- For the fabric shade, a light vacuuming with a soft brush attachment on a low setting can help remove dust that a cloth alone may not lift.